



Trimming cycle may be adjusted based on system reliability and critical needs. FY starts July 1 of each year.

- FY25
- FY27
- FY29
- FY26
- FY28
- Complete